



OCPP-80Y



⚠ Attention: Press FEED or re-start to reset cutter when it is covered stuck. If not, open lid and turn the gear to reset cutter.





OCPP-80Y



Attention: Press FEED or re-start to reset cutter when it or cover stuck, if not, open here and turn the gear to reset cutter

POWER ERROR PAPER FEED





OCPP-80Y





OCPP-80Y

